

Part Manuals

001506 Mirror Bracket Assembly

How to Install a Mirror & Brackets

Tools Needed



Electric drill with
5/64" drill bit



Phillips
Screwdriver



Important Note:

Instructions assume installation of mirror on unit that has not yet been mounted or recessed. If painting or staining of door or cabinet exterior is desired, it is recommended to do so before beginning mirror installation. If attaching to an already installed unit, it is recommended to have a partner assist with these instructions, with slight adjustments to steps.

Step One Inspect mirror & lay on door

Before beginning installation, inspect mirror for possible shipping damage. Then, with new unit on floor, lay mirror on top of unit door.



Step Two Install brackets

Slip brackets over each end of mirror. Holes will lay against bottom of door (not on mirror) so screws can be applied into the wood of the door.



Optional Pre-drill holes

Pre-drill a pilot hole into each screw using a 5/64 drill bit.



Step Three Install brackets

Drive small wood screws into each hole located on bracket. Your mirror is now installed and unit is ready to be mounted or recessed. After installation of unit, remove protective tape from brackets.



Installation Complete!